





Instructions

Instrucciones

Gebrauchs

Instructions

## COMPARATIVE SIZE WITH THE HUMAN FIGURE



## FILLING THE OIL (HIDROIL)

The oil is delivered in an airtight and sealed container, outside the condenser for safety measures in transportation. Therefore, after placing the antenna in vertical position, you must enter the oil.

1- Remove the two screws, and through one of the holes you must enter the oil, using the funnel that we have delivered.



2- In the cavity you have to introduce all the oil, to speed up the filling process, which is slow, we advise you to suck the air through the other hole with the help of a vacuum cleaner, the filling will be faster.



3- Replace the screws again, gently. The antenna is ready for use.